



**STOCKLIST  
SUITABLE FOR SULZER BAH 22  
08.02.2012**



ENEX GmbH  
Schnackenburgallee 116  
22525 Hamburg  
Germany

phone + 49. 40. 54 72 16-0  
fax + 49. 40. 54 72 16-11

[www.enex-gmbh.de](http://www.enex-gmbh.de)  
[info@enex-gmbh.de](mailto:info@enex-gmbh.de)

Acc.to part-no. (Code) Description

on stock

Acc.to part-no. (Code)	Description	on stock
10665	020110 Sealing	qty on request
10666	087656 Rubber gasket between fresh air pipes	qty on request
6015	021727 Piston ring 9 mm	qty on request
6025	040356 Connecting rod screw with nut new execution	qty on request
6026	000557 Connecting rod bush	qty on request
6034	062886 Pair conn. rod bearing, Std.	qty on request
6062	067446 Bearing shell half	qty on request
6062+6077	000563 Pair crankshaft bearing std.	qty on request
6063	000565 Thrust bearing half std.	qty on request
6077	020537 Main bearing shell, upper	qty on request
6100	067116 Gear	qty on request
6101	056265 Toothed wheel	qty on request
6103	008220 Drive wheel for steering shaft	qty on request
6227	008015 Press. spring f.starting valve	qty on request
6234	008016 Push rod complete	qty on request
6235	008208 Connection for push rod	qty on request
6276	032628 Joint ring	qty on request
6309	053429 Fuel valve cap nut	qty on request
6313	029227 Spring	qty on request
6315	017780 Adjusting set screw with lock nut for fuel valve	qty on request
6315	044885 Nut	qty on request
6316	009282 Venting screw for fuel valve	qty on request
6322	032253 Joint ring	qty on request
6333	056715 Clamp cone of inlet/exh.valve	qty on request
6334	053985 Valve cap	qty on request
6335	009280 Suction + exhaust valve spring	qty on request
6336	053986 Spring cap	qty on request
6337	000581 Rocker arms	qty on request
6347	017778 Bush	qty on request
6348	000583 Pin	qty on request
6349	023882 Lubricator	qty on request
6350	017777 Circlip	qty on request
6353	001685 Upper gasket	qty on request
6356	001686 Lower gasket for inlet/exhaust valve cone	qty on request
6378	056713 Spring	qty on request
6381	008018 Valve guide for In/exhaust valve cone	qty on request
6384	000585 Cap nut	qty on request
6503	066328 Pump body	qty on request
6510	021120 Spring for fuel pump	qty on request
6525+7431	018016 Set plunger with guide bush for suction + overflow	qty on request
6529	018018 Safety valve	qty on request
6534	056624 Spring	qty on request
6568	017773 Spindle for suction controll plunger	qty on request
6651	029693 Front bearing cover	qty on request
6652	029590 Rear bearing cover	qty on request
6654	029487 Bush	qty on request
6654	051555 Bush, large	qty on request
6656	021021 Forced lubricating pump cog wheel complete with nut	qty on request
6659	077961 Driving gear wheel	qty on request
6660	084522 Driving gearwheel for forced lub pump(on cranksha	qty on request
7060	040259 Lubricating stud for fuel pump	qty on request

Acc.to part-no. (Code)	Description	on stock
7115	000028 Spring cap with 2 insertion collar	qty on request
7328	002650 O - Ring Nit.	qty on request
7385	030809 Sealing ring	qty on request
7386	008043 Joint ring	qty on request
7386	036667 Joint ring	qty on request
7387	017769 Joint ring	qty on request
7388	015883 Joint ring	qty on request
7389	015884 Joint ring	qty on request
7431	041812 Plunger for suction overflow valve	qty on request
7431+6525	044746 Set plunger with guide bush for suction + overflow	qty on request
7435	015882 Suction overflow valve spring	qty on request
7442	015886 Joint ring	qty on request
7455	015885 Joint ring	qty on request
7455	046415 Gasket ring	qty on request
7460	021725 Screw plug	qty on request
7496	067448 Circlip	qty on request
7772	005482 Safety disk	qty on request
7932	052886 Joint ring	qty on request
7933	008116 Indicator cock	qty on request
8340	087651 Gasekt to exhaust pipe	qty on request
8750	033711 Starting valve press.flange	qty on request
8755	020530 Pressure spring	qty on request
9283	061017 Filter sieve for filter insert; large executio	qty on request